

Manual

RESIDENTIAL REVERSE OSMOSIS Clean Water Line/R.O. Water Drain Line/Rejected Water Feed Line/Water Supply

1. THE YELLOW TUBE IS INSTALLED ON THE FEED WATER SUPPLY.



2. PLACE BLACK TUBE ON TO THE HOUSEHOLD DRAIN.

REVERSE OSMOSIS MEMBRANE AND FILTER CARTRIDGE REPLACEMENT SCHEDULE

SEDIMENT CARTRIDGE - CHANGE WHEN VISIBLY DIRTY (4 TO 8 MONTHS)

R.O. MEMBRANE - SHOULD BE CHANGED EVERY 1.5 TO 2 YEARS.

CARBON CARTRIDGE - CHANGE AT THE SAME TIME THE R.O. MEMBRANE IS CHANGED.